

Marcos Silva General Motors Mercosul Engenharia de Manufatura – Body Systems


FLEX FIXTURE STRATEGY IMPLEMENTATION

ME QUALITY ASSURANCE



FLEX FIXTURE STRATEGY





Dedicated HF = CMM Measurement / Portable arm

CVER ASM





MP (New Scope)









No dedicated HF = Trouble Shooting in free state (Helix system)

Vertical Base Grid



Horizontal Base Grid (2x)



Current





All new programs legacy adaptation Stamped Parts



RPS Reuse:

All P&A

New Asm/ Parts

Plant space savings (48m2)



RPS/Datum

MP "Trouble Shooting"


ScanBox 7260 (Measurement)



CHECKING FIXTURES EXAMPLES

Supplier: Carl Zeiss Fixtures Systems GMB

Vertical base





Horizontal base



GEM FLEXIBLE HOLDING FIXTURE FOR SUBS

Implemented Flexible Holding Fixture for Subs (scan box measurement system equipment) to be stored in small cabinet, reducing storage space at plant floor.





BENEFITS

Smaller storage space;

Easy/fast to position the units;

Flexibility & Accuracy;

Horizontal/Vertical base reuse for future programs;

FLEX FIXTURE IMPLEMENTATION EQUIPMENT MEASUREMENT CAPACITY

VIRTUAL ANALYSIS

VIRTUAL SCANBOX, GD&T AND MATH DATA VALIDATION




VIRTUAL ANALYSIS

GOM VMR SOFTWARE

The positions for the Scanbox camera(gray squares) are created to capture all the matching areas and important spots in the product.

If there is any problem in this measurement we evaluate what can be done and the best solution for each case.


For solution examples, some additional reference towers can be positioned to add some virtual targets, the height of the fixture can be changed or a more deep project change can be needed, in some cases.




Video 1 – Scanning simulation

VIRTUAL ANALYSIS

After the fixture is pre-projected by supplier, all math data needs to be imported to the Scanbox software where all the analysis is done.



SUV Front rails example



Reference towers with targets (green)

 The virtual targets(Reference adhesive points) are created and set to be considered as the reference by the scan (green points).

VIRTUAL ANALYSIS

OUT COMES TO SUPPLIER

If no change is needed, supplier can go ahead with the construction. If some kind of improvement is needed, then the Scanbox analysis is done with the new math model of the fixture, to validate it.

In the final math model, Datums and GD&T are also evaluated and if some kind of issue is found, the corrections are maiden.




Picture 5 – Scanned area example (gray)


Virtual Analises - Scanbox simulation sofware

BENEFITS:

- Robust fixture from the beginning;
- Validation of Scanbox measurement;
- All the important surfaces/points in each product captured, to evaluate its quality;
- Capture all fixtures interference in advance;
- No reworks, no additional cost.



Virtual Analises – Scanbox simulation sofware





FLEX FIXTURE IMPLEMENTATION

SCAN BOX INITIATIVES















Measurement Report Customization

Scope: Customize Measurement Report customization to replace current CMM Measurement Reports of Stamped and Injected Parts
















AX	NOMINAL	MEAS	+TOL	-TOL	DEV		
×	3329,85	3330,21	0,5	0,5	0,36		
Y	-494,78	-494,81	0,5	0,5	-0,03		
Z	359,89	359,6	0,5	0,5	-0,29		
T	0	0,37	0,5	0,5	0,37		pass
2154TL	0						
AX	NOMINAL	MEAS	+TOL	-TOL	DEV		
X	3330,77	3331,03	0,5	0,5	0,26		
Y	-490,89	-491,56	0,5	0,5	-0,67		
Z	356,2	356,18	0,5	0,5	-0,02		
T	0	0,67	0,5	0,5	0,67		fail
0001XF	IR.						
AX	NOMINAL	MEAS	+TOL	-TOL	DEV	In-Plane	pass
×	3120,63	3120,77	0,75	0,75	0,13		
Y	531,75	531,73	0,75	0,75	-0,02		
Z	1173,51	1173,87	0,75	0,75	0,36		
D	14	14,1	0,1	0	0,1		Diam pass
T	0	0,2	0,75	0,75	0,2	0,327	LOC pass-B
						BONUS	0,05
0003XF	IR						
AX	NOMINAL	MEAS	+TOL	-TOL	DEV	In-Plane	pass
X	3121,22	3121,39	0,75	0,75	0,17		
Υ	384,5		0,75	0,75			
Z	1265,35	1265,33	0,75	0,75	-0,02		
D	13,2		0,1	0			Diam pass
T	0	0,14	0,75	0,75	0,14	0,578	LOC pass
						BONUS	0





Automatic R&R and Capabilities Measurement

Scope: Create special routines to automatically perform R&R and Capabilities Measurements (including Cp and Cpk tendencies)




R&R - MACRO (MSA)




Part Average	-0.68	-0.68	-0.67	-0.67	-0.64	-0.01 -0.80	-0.77	-0.79	-0.79	Rp	0.20
Equipment Variation:	0.05		σ _{re}	epeatability	0.01	%EV-Tol	5.5%	%EV-TV	14.5%	R-Dbl-Bar	0.02
Appraiser Variation:	0.00		σ_{rep}	roducibility	0.00	%AV-Tol	0.0%	%AV-TV	0.0%	X-bar Diff	0.00
R & R:	0.05			$\sigma_{R\&R}$	0.01	RR-Tol	5.5%	%RR-TV	14.5%	UCL R chart	0.04
Part Variation:	0.37			σ_{PV}	0.06			%PV-TV	98.9%	LCL R Chart	0.00
Total Variation:	0.38			στν	0.06					Max Range	0.08
										Range Stable?	No

Jewell Radii Measurement

Scope: Create Jewell Radii Measurement Routine and Reports to report at program gates





GOM Inspect Professional Curves GOM's approach


Curvature, radii, flush, gap, etc. should provide the same advantages as full-field surfaces.


Merging the full-field inspection world with the single point

Provide a maximum of information for all inspection elements

Let the user decide at any later point where he wants detailed information, i.e. where he wants to pick single points for in depth analysis

The "Curves" concept provides this high information density










Feature lines Measurement

Scope: Create Feature Lines Measurement Routine and Reports to report at program gates






GOM Inspect Professional Curves Advantages of curve-based inspection Condensed visualization Focus on functional properties Bridge the gap between point-based and surface-based inspection Inspection applications Curve deviations



Character lines

Dimensional Alarm Notification

Scope: Understand ScanBox capability to release dimensional alarm notification similar to GDIS for Stamped and Injected Parts with Variation Trends



THANK YOU